

## MYZONE RESTART

Every now and again, the MYZONE stick will require a reboot. In order to do this, locate the MYZONE stick inside the BLAZE AV Rack. It will be plugged into another piece of equipment and have several cables connected to it.

There are two ways to reboot it:

- 1 Press and hold the power button until the blue light (3) switches off. When its off, press it once again to restart it.
- 2 Remove the Power Cable (Micro USB), wait 5 seconds, then re-insert it. After it's been re-inserted, press the power button (1) and make sure the blue light comes back on.

When resetting the MYZONE stick, DO NOT unplug any of the other cables (the two full-size USB plugs).

