

MICROPHONE SYSTEM PAIRING

The Shure digital microphone receiver should be located behind one of the TVs in the BLAZE Studio.

In order to pair a new beltpack to the receiver, please do the following:

1. Locate the Mic Receiver and ensure it is switched on.

2. Press and hold the 'Link' button on the receiver for 3 seconds ①. The Blue LED directly above the 'Link' button ② will start flashing.

3. Turn the Beltpack on ③ and press the 'Link' button located behind the flap on the side of the beltpack ④ for 3 seconds. The green LED on top will start flashing ⑤. This needs to be done within 5 seconds of turning the beltpack on.

4. Once pairing is complete, the LED lights on the Receiver ② and Beltpack ⑤ will light up solid. This indicates that the pairing process has been successful.

If the pairing process is unsuccessful, there could be a firmware compatibility issue. Please contact the Hutchison Technologies Helpdesk for further assistance.

