

The BLAZE music server takes care of the audio tracks, lighting and class selection for BLAZE classes.

There could be an issue with the Music Server PC if you find that:

- No audio track plays when 'Demo' is selected or when you unlock the AV iPad.
- No Tracks are available to select when starting a class.
- The lighting doesn't come on when you select 'Demo' or unlock the AV iPad.

If you have time, you should always try to restart the main music server PC:

- 1. Hold down the power button ① until the light turns off.
- 2. Press the power button ① once more to turn the PC back on (light will come back on).
- 3. Wait 3 minutes, then try and use the system again.

If you are still having the same problems, please carry onto the next page which explains how to switch over to the backup music server PC.

MUSIC SERVER FRONT







In the BLAZE AV Rack, there are two Music Server PCs. a main and a backup (these should be labelled accordingly).

To change over to the backup PC:

- 1. Ensure that the Power is switched off on both machines 20 (no lights visible).
- 2. Move the Audio Jack from the main music server ③ to the audio socket on the backup server ⑤.
- 3. Move the Ethernet Cable from the main music server ② to the ethernet port on the backup server ③.
- 4. Move the USB Cable from the main music server 3 to the USB Port on the backup server 3 (ensure the USB port used is the same as the main server).
- 5. Finally, Move the Power Cable from the the main music server 6 to the power socket on the backup server 6.

The backup server should come on automatically as soon as the power cable is plugged in.

After this is done, please wait 3 minutes then try and use the system again.

NOTE: The Backup PC won't be set to the correct 'Daily Class'. In order to change it to the correct class, please contact the Hutchison Technologies Helpdesk and someone will be able to assist.

MAIN MUSIC SERVER FRONT



BACKUP MUSIC SERVER FRONT



MAIN MUSIC SERVER REAR



BACKUP MUSIC SERVER REAR



